

# TrackMate – How to use

Tire additives from TrackMate are carefully designed to meet the challenges on any track using rubber tires. The different mixtures ensure that you can achieve the best traction in any condition.

## GREEN - Neutral Grip:

This additive provides consistent traction with less overall grip, and is intended for use on very high grip surfaces.

You can alter the grip level by changing the active time in which the additive is applied and active on the tires.

Usage: Apply for typical 5 - 20 minutes. Wipe off tires before run.



## RED - High Grip:

This additive will provide lots of traction through the tire and is intended for use on low to medium grip surface conditions.

You can alter the grip level by changing the active time in which the additive is applied and active on the tires.

Usage: Apply for typical 15 - 30 minutes. Wipe off tires before run.



## BLUE - Ultra High Grip:

This additive will give you maximum grip and is ideal for tracks with low surface grip. This additive will activate the tire a lot.

Blue additive is also good for breaking in new tires where needed.

You can alter the grip level by changing the active time in which the additive is applied and active on the tires.

Usage: Apply for typical 5 - 20 minutes. Wipe off tires before run.



## Speed Secrets

$$\text{TRACTION} = \text{Surface GRIP} + \text{Tire GRIP}$$

Ideal traction for good and consistent lap times is the result of a match between the surface grip and the tire grip. Traction which is either insufficient or too high will not get you the maximum performance out of your car. The correct tire additive can help your tires match the surface grip and get the perfect traction.

Surface  
↑ HIGH  
--- GRIP ---  
↓ LOW

- Apply GREEN and let it work for 3-5 minutes and then wipe off.
- Apply GREEN and let it work for 10-20 minutes and then wipe off.
- Apply RED and wipe off immediately. Apply GREEN for 10-20 minutes and then wipe off.
- Apply RED and let it work for 5-10 minutes and then wipe off.
- Apply RED and let it work for 15-30 minutes and then wipe off.
- Apply BLUE and wipe off immediately. Apply RED for 10-20 minutes and then wipe off.
- Apply BLUE and let it work for 10-20 minutes and then wipe off.